

# VelociCalc™ Air Velocity Meter



Model 9515

Operation and Service Manual

P/N 1980555, Revision G  
August 2023



# Start Seeing the Benefits of Registering Today!

Thank you for your TSI® instrument purchase. Occasionally, TSI® releases information on software updates, product enhancements and new products. By registering your instrument, TSI® will be able to send this important information to you.

<http://register.tsi.com>

As part of the registration process, you will be asked for your comments on TSI products and services. TSI's customer feedback program gives customers like you a way to tell us how we are doing.

**Copyright©**

TSI Incorporated / 2007–2023 / All rights reserved.

**Address**

TSI Incorporated / 500 Cardigan Road / Shoreview, MN 55126 / USA

**Fax No.**

(651) 490-3824

**LIMITATION OF WARRANTY AND LIABILITY** (effective February 2015)

(For country-specific terms and conditions outside of the USA, please visit [www.tsi.com](http://www.tsi.com).)

Seller warrants the goods, excluding software, sold hereunder, under normal use and service as described in the operator's manual, to be free from defects in workmanship and material for **24 months**, or if less, the length of time specified in the operator's manual, from the date of shipment to the customer. This warranty period is inclusive of any statutory warranty. **This limited warranty is subject to the following exclusions and exceptions:**

- a. Hot-wire or hot-film sensors used with research anemometers, and certain other components when indicated in specifications, are warranted for 90 days from the date of shipment;
- b. Pumps are warranted for hours of operation as set forth in product or operator's manuals;
- c. Parts repaired or replaced as a result of repair services are warranted to be free from defects in workmanship and material, under normal use, for 90 days from the date of shipment;
- d. Seller does not provide any warranty on finished goods manufactured by others or on any fuses, batteries or other consumable materials. Only the original manufacturer's warranty applies;
- e. This warranty does not cover calibration requirements, and seller warrants only that the instrument or product is properly calibrated at the time of its manufacture. Instruments returned for calibration are not covered by this warranty;
- f. This warranty is **VOID** if the instrument is opened by anyone other than a factory authorized service center with the one exception where requirements set forth in the manual allow an operator to replace consumables or perform recommended cleaning;
- g. This warranty is **VOID** if the product has been misused, neglected, subjected to accidental or intentional damage, or is not properly installed, maintained, or cleaned according to the requirements of the manual. Unless specifically authorized in a separate writing by Seller, Seller makes no warranty with respect to, and shall have no liability in connection with, goods which are incorporated into other products or equipment, or which are modified by any person other than Seller.

The foregoing is **IN LIEU OF** all other warranties and is subject to the **LIMITATIONS** stated herein. **NO OTHER EXPRESS OR IMPLIED WARRANTY OF FITNESS FOR PARTICULAR PURPOSE OR MERCHANTABILITY IS MADE. WITH RESPECT TO SELLER'S BREACH OF THE IMPLIED WARRANTY AGAINST INFRINGEMENT, SAID WARRANTY IS LIMITED TO CLAIMS OF DIRECT INFRINGEMENT AND EXCLUDES CLAIMS OF CONTRIBUTORY OR INDUCED INFRINGEMENTS. BUYER'S EXCLUSIVE REMEDY SHALL BE THE RETURN OF THE PURCHASE PRICE DISCOUNTED FOR REASONABLE WEAR AND TEAR OR AT SELLER'S OPTION REPLACEMENT OF THE GOODS WITH NON-INFRINGEMENTS.**

TO THE EXTENT PERMITTED BY LAW, THE EXCLUSIVE REMEDY OF THE USER OR BUYER, AND THE LIMIT OF SELLER'S LIABILITY FOR ANY AND ALL LOSSES, INJURIES, OR DAMAGES CONCERNING THE GOODS (INCLUDING CLAIMS BASED ON CONTRACT, NEGLIGENCE, TORT, STRICT LIABILITY OR OTHERWISE) SHALL BE THE RETURN OF GOODS TO SELLER AND THE REFUND OF THE PURCHASE PRICE, OR, AT THE OPTION OF SELLER, THE REPAIR OR REPLACEMENT OF THE GOODS. IN THE CASE OF SOFTWARE, SELLER WILL REPAIR OR REPLACE DEFECTIVE SOFTWARE OR IF UNABLE TO DO SO, WILL REFUND THE PURCHASE PRICE OF THE SOFTWARE. **IN NO EVENT SHALL SELLER BE LIABLE FOR LOST PROFITS,**

**BUSINESS INTERRUPTION, OR ANY SPECIAL, INDIRECT, CONSEQUENTIAL OR INCIDENTAL DAMAGES.** SELLER SHALL NOT BE RESPONSIBLE FOR INSTALLATION, DISMANTLING OR REINSTALLATION COSTS OR CHARGES. No Action, regardless of form, may be brought against Seller more than 12 months after a cause of action has accrued. The goods returned under warranty to Seller's factory shall be at Buyer's risk of loss, and will be returned, if at all, at Seller's risk of loss.

Buyer and all users are deemed to have accepted this LIMITATION OF WARRANTY AND LIABILITY, which contains the complete and exclusive limited warranty of Seller. This LIMITATION OF WARRANTY AND LIABILITY may not be amended, modified or its terms waived, except by writing signed by an Officer of Seller.

**Service Policy**

Knowing that inoperative or defective instruments are as detrimental to TSI as they are to our customers, our service policy is designed to give prompt attention to any problems. If any malfunction is discovered, please contact your nearest sales office or representative, or call TSI's Customer Service department at (800) 680-1220 (USA) or (001 651) 490-2860 (International) or visit [www.tsi.com](http://www.tsi.com).

**Trademarks**

TSI and the TSI logo are registered trademarks of TSI Incorporated in the United States and may be protected under other country's trademark registrations.

# CONTENTS

<b>CHAPTER 1 UNPACKING AND PARTS IDENTIFICATION .....</b>	<b>1</b>
<b>CHAPTER 2 SETTING-UP.....</b>	<b>3</b>
Supplying Power to the Model 9515 VelociCalc® Air Velocity Meter.....	3
Installing the Batteries .....	3
Using The Telescoping Probe .....	3
Extending The Probe.....	3
Retracting The Probe .....	3
<b>CHAPTER 3 OPERATION .....</b>	<b>5</b>
Keypad Functions .....	5
<b>CHAPTER 4 MAINTENANCE.....</b>	<b>7</b>
Recalibration.....	7
Cases.....	7
Storage .....	7
<b>CHAPTER 5 TROUBLESHOOTING.....</b>	<b>9</b>
<b>APPENDIX A SPECIFICATIONS.....</b>	<b>11</b>

*(This page intentionally left blank)*

# Chapter 1

## **Unpacking and Parts Identification**

---

Carefully unpack the instrument and accessories from the shipping container. Check the individual parts against the list of components below. If anything is missing or damaged, notify TSI® Incorporated immediately.

1. Carrying case
2. Instrument

*(This page intentionally left blank)*



# Chapter 2

## Setting-up

---

### Supplying Power to the Model 9515 VelociCalc™ Air Velocity Meter

The Model 9515 is powered with four size AA batteries.

#### Installing the Batteries

Insert four AA batteries as indicated by the diagram located on the inside of the battery compartment. The Model 9515 is designed to operate with either alkaline or NiMH rechargeable batteries, although it will not recharge NiMH batteries. Battery life will be shorter if NiMH batteries are used. Carbon-zinc batteries are not recommended because of the danger of battery acid leakage.

#### Using the Telescoping Probe

The telescoping probe contains the velocity and temperature sensors. When using the probe, make sure the sensor window is fully exposed and the orientation dimple is facing upstream.

#### NOTICE

For temperature measurements, make sure that at least 3 inches (7.5 cm) of the probe is in the flow to allow the temperature sensor to be in the air stream.

#### Extending the Probe

To extend the probe, hold the handle in one hand while pulling on the probe tip with the other hand. **DO NOT** hold the cable while extending the probe as this prevents the probe from extending.

#### Retracting the Probe

To retract the probe, hold the handle in one hand while pulling gently on the probe cable with the other hand.

*(This page intentionally left blank)*

# Chapter 3

## Operation

---

### Keypad Functions

<b>ON/OFF Key</b>	Press to turn the Model 9515 on and off. During the power up sequence the display will show the following: Model Number, Serial Number, Software Revision, and Last Date Calibrated.
<b>ft/min / m/s Key</b>	Pressing this key changes the display to read air velocity.
<b>°C / °F Key</b>	Pressing this key changes the display to read temperature.
<b>Changing Units</b>	To change units, first put the desired measurement (air velocity or temperature) on the display. Then press and hold the left, unlabelled key for five seconds. Finally, use the ▲▼ and <b>ENTER</b> key to select the units.

*(This page intentionally left blank)*

# Chapter 4

## Maintenance

---

The Model 9515 requires very little maintenance to keep it performing well.

### Recalibration

To maintain a high degree of accuracy in your measurements, TSI® recommends that you return your Model 9515 to TSI® Incorporated for annual recalibration. Please contact one of TSI's offices or your local distributor to make service arrangements and to receive a "Service Request" number. To fill out an online "Service Request" form, visit TSI's website at [tsi.com/service](http://tsi.com/service).

#### U.S. & International

TSI Incorporated  
500 Cardigan Road  
Shoreview MN 55126-3996  
Tel: (800) 680-1220  
(651) 490-2860  
Fax: (651) 490-3824

### Cases

If the instrument case or storage case needs cleaning, wipe it off with a soft cloth and isopropyl alcohol or a mild detergent. Never immerse the Model 9515. If the enclosure of the Model 9515 becomes broken, it must be replaced immediately to prevent access to hazardous voltage.

### Storage

Remove the batteries when storing the unit for more than one month to prevent damage due to battery leakage.

*(This page intentionally left blank)*


# Chapter 5

## Troubleshooting

Table 5-1 lists the symptoms, possible causes, and recommended solutions for common problems encountered with the Model 9515. If your symptom is not listed, or if none of the solutions solves your problem, please contact TSI® Incorporated.

**Table 5-1: Troubleshooting the VelociCalc™ Model 9515**

Symptom	Possible Causes	Corrective Action
No Display	Unit not turned on	Switch unit on.
	Low or dead batteries	Replace batteries.
	Dirty battery contacts	Clean the battery contacts.
Velocity reading fluctuates unstable	Fluctuating flow	Reposition probe in less-turbulent flow
Instrument Error message appears	Fault in instrument	Factory service required on instrument.

	<b>WARNING</b>
	Remove the probe from excessive temperature immediately: excessive heat can damage the sensor. Operating temperature limits can be found in <a href="#">Appendix A, Specifications</a> .

*(This page intentionally left blank)*



# Appendix A

## Specifications

---

Specifications are subject to change without notice.

### Velocity:

Range: 0 to 4000 ft/min (0 to 20 m/s)  
Accuracy<sup>1&2</sup>:  $\pm 5\%$  of reading or  $\pm 5$  ft/min ( $\pm 0.025$  m/s),  
whichever is greater  
Resolution: 1 ft/min (0.01 m/s)

### Temperature:

Range: 0 to 200°F (-18 to 93°C)  
Accuracy<sup>3</sup>:  $\pm 0.5$ °F ( $\pm 0.3$ °C)  
Resolution: 0.1°F (0.1°C)

### Instrument Temperature Range:

Operating (Electronics): 40 to 113°F (5 to 45°C)  
Operating (Probe): 0 to 200°F (-18 to 93°C)  
Storage: -4 to 140°F (-20 to 60°C)

### External Meter Dimensions:

3.3 in. × 7.0 in. × 1.8 in. (8.4 cm × 17.8 cm × 4.4 cm)

### Meter Weight:

Weight with batteries: 0.6 lbs (0.27 kg)

### Power Requirements:

Four AA-size batteries (included)

<sup>1</sup> Temperature compensated over an air temperature range of 40 to 150°F (5 to 65°C).

<sup>2</sup> The accuracy statement of  $\pm 5.0\%$  of reading or  $\pm 5$  ft/min ( $\pm 0.025$  m/s), whichever is greater, begins at 30 ft/min through 4000 ft/min (0.15 m/s through 20 m/s).

<sup>3</sup> Accuracy with instrument case at 77°F (25°C), add uncertainty of 0.05°F/°F (0.03°C/°C) for change in instrument temperature.

*(This page intentionally left blank)*





Distributed by:

Kenelec Scientific Pty Ltd  
1300 73 22 33  
sales@kenelec.com.au  
www.kenelec.com.au



**Knowledge Beyond Measure.**

**TSI Incorporated** – Visit our website [www.tsi.com](http://www.tsi.com) for more information.

**USA** Tel: +1 800 680 1220

**India** Tel: +91 80 67877200

**UK** Tel: +44 149 4 459200

**China** Tel: +86 10 8219 7688

**France** Tel: +33 1 41 19 21 99

**Singapore** Tel: +65 6595 6388

**Germany** Tel: +49 241 523030

P/N 1980555 Rev G

©2023 TSI Incorporated

Printed in U.S.A.

